

Installing The Wingtip Siding

Starting at the leading edge of the wingtip you will be installing the siding with the under side edge facing forward. The top of all the wingtip siding will have to be cut. It's easiest to align the bottom edge of the wingtip siding with the bottom of the wingtip frame and screw the siding in place.

Start with the wingtip leading edge siding. Make sure the siding under edge is facing forward towards the truss. Align the bottom edge of the panel with the bottom of the bottom frame rail and then mark the top leading edge where it will have to be notched to fit around the truss. Cut the notch and screw the panel in place. Install the second panel.

Using a pencil, mark the wingtip frame at the center of the panel ridges so later you can properly install the closure-strips. Do not use the story pole here to make the pencil marks because the angle of the roof requires that the pencil marks be farther apart.

Next mark the cut line at the top of the panels. Remove the panels and cut them. Starting at the leading edge of the top and bottom wingtip frame rail, install the closure-stripping. Re-attach the panels after they are cut.

