

Tools Required

- Shovel
- Electric hand drill
- Circular saw (skill saw)
- Screw driver
- Nut driver
- Hack saw
- Drills 1/8, 5/16, sheet metal step drill
- Hammer
- 50 ft steel tape measure (2 required)
- Mason line (chalk line) (approximately 200')
- Abrasive cutoff wheels (approximately 10)
- Crescent wrench
- Box wrenches
- C-Clamps (2 Required)
- Retractable Measuring Tape