

Installing Hinged Nose Door Panel

Install the hinged nose panel first. Use C-clamps to lift and hold the panel in place. Center the panel in the tailhouse opening.



Adjust the top edge of the hinged nose panel $\frac{1}{2}$ " below the bottom edge of the truss and screw hinges in place using #14 X 1" self-taping screws.

